



4階




◎ : 非常口・非常階段

△ : 避難ハッチ

3階



2階



1階

